

Roberts Precision Tools Ltd.

Fitting Instructions

Indicators



Fitting Instructions:

Step One

Mark centre position of indicator 75mm from the door edge.

Step Two

Drill four 6mm holes equal about this point at 35mm centre's.

Step Three

Mark centre slot 13mm x 35mm using equal about centre.

Step Four

Using a 13mm drill, Drill end holes.

Step Five

Using a jigsaw or router cut a 13mm slot joining the two 13mm holes

Step Six

Secure front plate green insert onto the door using 5mm x 30mm (25mm if solid grade laminate is being used) Taking care to insert the trough bolt into the red plastic indicator.

Step Seven

Before mounting the front cover plate, ensure a free and easy movement.

Step Eight

Mark position of the keep and drill pilot holes to suit 5/8" number 8 screws, drill through if wanting to use a through bolt. DO NOT use a power screwdriver to mount keep.

Step Nine

Position rubber buffers on pilaster close to the keep.

